

Loading Suggestions

The values presented in this document are recommendations only. It is the driver's responsibility to know the dimensions of the trailer, to load only the size of cattle that will safely and humanely fit the trailer and to adhere to the maximum legal load limit for the states in which they are operating.

Compartment Weight	Average Weight of Cattle											
	400	500	600	700	800	900	1000	1100	1200	1300	1400	1500
1,500	3	3	2	2	1	1	1	1	1	1	1	1
4,000	10	8	6	5	5	4	4	3	3	3	2	2
4,500	11	9	7	6	5	4	4	3	3	3	2	2
6,000	15	12	10	8	7	6	6	5	5	4	4	4
8,000	20	16	13	11	10	8	8	7	6	6	5	5
9,000	22	18	15	12	11	10	9	8	7	6	6	6
20,000	50	40	33	28	25	22	20	18	16	15	14	13
21,000	52	42	35	30	26	23	21	19	17	16	15	14

